

Panel height 4' and 3'

For panel height 4':

3 cross stiffeners, of which 3 are multi-function profiles with welded DW-threaded nuts. The only exception is the 6" wide panel, which has no multi-function profile.

2 symmetrically arranged tie holes per panel height.

For panel height 3':

1 cross stiffener, of which 1 is a multi-function profile with welded DW-threaded nuts. The only exception is the 6" wide panel, which has no multi-function profile.

1 symmetrically arranged tie hole per panel height.

Attention

Unused tie holes need to be closed with plugs D27/30.

