

Panel height 6'

For panel height 6':

5 cross stiffeners, of which 5 are multi-function profiles with welded DW-threaded nuts. 2 symmetrically arranged tie holes per panel height.

Attention

Unused tie holes need to be closed with plugs D 27/30.

